

X2150 Smartcard Software Upgrade

The X2150 software may be upgraded using the X2150's internal smartcard reader from specially created upgrade cards. To upgrade the software using this method:

1. Power down the X2150 and remove the base of the unit.
2. Carefully remove the installed system card from its holder by sliding towards the front of the keyboard and store in a safe place. (Avoid touching the gold contacts).
3. Slide the software upgrade card into the vacated card slot.
4. Hold down the record and fast-forward keys whilst restoring power.



The yellow 'SHIFT' light will illuminate to indicate that the inserted card has been recognised as containing valid software update code and the software will start to load. Do not interrupt this process once the yellow light is showing as this may permanently corrupt the existing and/or new software version.

After approximately 35 seconds, the yellow light will extinguish and the green 'VCR' light will illuminate to indicate a successful update.

5. Power down the X2150 and carefully remove the upgrade card*.
6. Re-install the system card and refit the metal base plate.

The new software will be installed and ready to run. You may check the version number by selecting 1.SYSTEM, 6.KBD from the main menu.

***IMPORTANT** Always remember to remove the upgrade card before attempting to change any of the X2150 parameters. Failure to do so will corrupt the software upgrade data on the card.