

## Playing Back from your Digital Video Recorder

- 1 From the **Live** video screen press the 'Play' button on your digital video recorder.
- 2 From the **Playback** menu, select your chosen search type from the following options:
  - Time Search
  - Event Search
  - Record Search
  - Date Search
- 3 Press 'Enter' on your desired search method.
- 4 Select the start/end date and time, highlight 'OK' and press enter.
- 5 To exit playback press 'Stop' and then 'ESC'

## Backing up from your Digital Video Recorder to DVD

- 1 From **LIVE** video screen press the 'Backup' button on the front of your digital video recorder.
- 2 From the **Backup** menu, select the following:
  - Select 'Device' as USB
  - Go down to 'Detect Device', press Enter
  - Select Desired channels for backup
  - Enter Start time
  - Enter Finish time
  - If you wish to format your USB device, select 'erase all USB file' (optional)
- 3 Make sure the 'Approximate Size' is lower then the 'USB free space'
- 4 Highlight and click 'OK'
- 5 Wait till backup complete message appears, then select 'OK'.
- 6 It should now show you the backup screen again.
- 7 Now press 'ESC' button on the front of unit till LIVE video is displayed again.