

Merit Lilin Technical Support Document

Document Number: Q00031
Date: 2/19/2010
Dept: Technical Support, Taipei

Subject: How to use VLC to play network stream for LILIN's H.264 IP cameras.

Firmware Requirement:

Firmware version: 0.3.28 or above is required.
VLC version: 1.0.5


Product Supported

IPS025/030/035, MI025/030/035, PS203/212, IPR454/8, VS012, IPD552


Summary:

This document describes the way to use VLC player to play network stream for LILIN H.264 IP cameras.

Step #1: Disable "Drop late frames" and "Skip frames" at VLC->Preferences->Video.




Step #2: Set de-interlace mode to "X" at VLC->Video->de-interlace.



Step #3: Open Network Stream

Click on Media->Open Network Stream at main menu of VLC.

To open HTTP network stream, please type <http://59.124.49.45/getstream> at Address field.
Please set Caching option to 70ms to minimize the latency.



Click on Media->Open Network Stream at main menu of VLC.

To open RTSP network stream, please type <rtsp://59.124.49.45/rtsp264> at Address field.
Please set Caching option to 70ms to minimize the latency.

