



Merit LILIN Application Note

How to register the P2P license on AHD DVR

Document Number : A00144

Date : 2018/03/13

Dept: Technical Support, Taipei


Subject: This document describes how to register the P2P license on a LILIN AHD DVR and how to connect to it using the NetViewer app and Windows software via P2P protocol.

Device Supported: LILIN AHD DVRs.

How to register the P2P license on an AHD DVR


Step 1: You will receive a barcode after buying a P2P license from LILIN dealers.

Step 2: Scan the barcode to get a P2P license.



Step 3: Make sure the AHD DVR is able to connect to the internet.

Step 4: Turn on the AHD DVR, go to Network Setup and apply the P2P license.





Step 5: If registration is successful, the barcode, the UID gets shown on the system information.




How to connect to the AHD DVR via P2P

There are 2 ways of connecting to the AHD DVR via P2P:

1. Netviewer App is for mobile devices.
2. Netviewer.exe is for Windows PC.

For mobile devices

- Step 1: Download the NetViewer App from the app store and install it on to the mobile device.
- Step 2: Execute NetViewer, click New and Scan QR code button.
- Step 3: After the QR code of AHD DVR has been scanned, all the DVR information will be imported automatically into each field.
- Step 4: Click the Save button.
- Step 5: Select one AHD DVR from DVR list for live viewing.





NetViewer.exe for PC

- Step 1: Download NetViewer software from <http://www.meritlilin.com/assets/uploads/support/file/Software-NetViewer%20Software-EN.zip>
- Step 2: Unzip Software-NetViewer Software-EN.zip, and execute NetViewer.exe
- Step 3: Key in the UID code of AHD DVR into Host and add port, user name, and password information
- Step 4: Click the Connect button to establish a connection to the DVR



Contact
Contact lilin.zendesk.com for technical support.