

Merit LILIN Application Note Interoperable test of Aimetis Software and LILIN IP Cameras

Document Number : A00031 Date : 08/02/2013 Dept : Technical Support, Taipei

Subject: Interoperable test of Aimetis software and LILIN IP cameras

Firmware Requirement:

LILIN iMEGAPRO camera firmware: version 1.0.509f or above LILIN L Series camera firmware: version 1.1.010 or above Aimetis Software: 6.12.0.1 (r43551), Device Pack Version: 1.0.6.1

Step #1:

Please use Aimetis Symphony Client to add LILIN cameras via "Server->Configuration".



Step #2:

On "Server Configuration", click on New button and Add a Network Camera.





Step #3: On "Server Configuration", enter the followings for connecting LILIN IP cameras:

- 1. Manufacture: ONVIF driver

- Manufacture. On Vir Giver
 Username: admin (default)
 Password: pass (default)
 Select "Resolution" and "Video Format", if necessary.
 Enable "Audio Input", if necessary.

Click on "Connect to Camera" button to retrieve LILIN IP camera information.

Server Configuration - [LILINTest] - D	levice	
- 🔁 Rules	Server 127.0.0.1	
□ ፵ Devices	Network Video Analytics Engines Analytics Configuration	
🔝 Licenses	Name Camera1	Discover Devices
- Notifications		
Storage	ID/Code	View on Web
. 127.0.0.1		Supported Features
- Server Farm	URL 192.168.1.185	
Carousels	e.g. 10.1.2.3 (port 80) 10.1.2.3:120	
	rtsp://10.1.2.3/mpeg4/1/media.amp (port 554)	
	Manufacturer ONVIF	
	Panasonic PanasonicHCM	
	Pelco Telco	
	Username admin Password ****	
	Connect to Camera	
	Camera Type	
	C Fixed C PTZ C Video Server	
	Resolution EPS Video Format Failover Movability	
	1920 x 1080 V 25 V H264 V Movable V	
	Support Direct Connect V Enable Audio Input Enable Audio Outou	rt
		OK Cancel

Step #4:

Click on "OK" button to return live video. You are now able to see live video from LILIN camera.

